

ASGA - LDC | ASHG - LTCA | ASHG - LTCB | ASHG - LECA | ASHG14LECA | ASHG - LMCA | ASHG - LEC | ASHG - LECB | ASHG - LUCA | ASHG - LJCA | ASHG - LFCA | ASHG - LFCF | RD - CC | RC - EC | RC - LC | RD - LAN | RD - UA | RD - TC - LDA - LAUJ | RD - LATN | RDA - LCTUJ | RDA - LKUC | LKUC | LKUC | LRDH - LTAL | RDG - LALU | RDG - LBLU | RDG - LBLT | RDG - LBTA | RDG - LDHA | RDG - LDLT | RDG - LDLB | RDG - LMLC | RC - UA | RCA - LATN | RCA - LCUU | RCF - LAU | RCF - LBL | RCG - LRUA | RCG - LRUE | RCG - LRVA | RCG - LVLB | RGF - LAC | RGG - LVCB | RGG - LVYA | RYG - LVTA | RYG - LVTB | RYF - LBT | RYFF - LBT | RYG - LRTE | RYC - LRAT | RYA - LBT | RYA - LCT | RJA - FRTA-S | RCA - URTA-S | RDA60FHTB-S | RDA - FMFA-S | RDA - FMTB-S | RDA - UMFA-S | RDA - OUMTB-S | RDA - OUMTB-S

GENERAL AC models

ASGA - AET 1 | ASGA - FMFA 1 | ASGA - FTFA 1 | ASGA - FTFA-A 1 | ASGA - JCC 1 | ASGG - LCFD 1 | ASGG - LJCA 1 | ASHA - LEC 1 | ASHA - LKC 1 | ASHB - LDC 1 | ASHG - LE 1 | ASHG14LE1 | ASHG - LECA 1 (except 07/12) | ASHG 7/12 LECA 1 | ASHG - LECB 1 | ASHG - LP 1 | ASHG - LFGA 1 | ASHG - LFFC 1 | ASHG - LCFD 1 | ASHG - LJ 1 | ASHG - LJCA 1 | ASHG - LLMCA 1 | ASHG - LT 1 | ASHG - LTCB 1 | ASHG - LTCU 1 | ASHG - LU 1,2 | ASHG - LUCA 1 | ASHG - UFADR 1 | ASHG - UFAR 1 | ASHG - LATE | ASHG - LACH | ASHA - GBCH | ASHA - LACH | ASHA - LATE | ASHE - GACH | ASHE - LACH | AGC - UIA-LM | ARG - A/R | ARG36ALD3 | ARG - ALCT | ARG45AL3 | ARG1BALCH (Check RC remote) | ARG60AUGA | ARG90ELC3 (Check RC remote) | ARG90TL3 (Check RC remote) | ARG - RLIC

ARG - RLC3 | ARG - UU | ARG60AUAK (Check RC remote) | ARG60FUAK (Check RC remote) | ARG60FUAL (Check RC remote) | ARG - FUAN (Check RC remote) | ARG60RUAK (Check RC remote) | ARG60UUAK (Check RC remote) | ARG18UUAL (Check RC remote) | ARG60UUAN (Check RC remote) | ARGa - FMTA | ARGa - FHTA | ARGg - LLLB-A | ARGg - LMLA-A | ARGg24LMTA | ARH - LUAN | ARH - UUAN | ARHA - LB | ARHA45LC | ARHA - LBTU | ARHA - LCTU | ARHC - LC | ARHC - LCTU | ARHC - LHtA | ARHF24LB | ARHF - LBLU | ARHF - LBTU | ARHG - LHtA | ARHG - LLtA | ARHG - LLtB | ARHG - LM | ARHG - LMLA | ARHG - LMLE | ARSA - UHTB | ARSA - UMTA | ARSA - UMTB | ARYG - LMLE | ARXD - GALH | ARX - GBTH | ARXK - GCLH | MSAR - RIY(N) | AR - UFAAR | ARXA - GALH | ARXA - GBLH | ARXA - LALH | ARXA - LALR | ARXA - LATF | ARXA - LATH | ARXA - LBLR | ARXB - GALH | ARXB - LALF | ARXB - LALH | ARXB - LATF | ARXB - LATH | ARXB - LATR | ARXC - GATH | ARXC - GBTH | ARXC - LATF | ARXC - LATH | ARXD - LATH | ARXH - GTAH | AUG - UI A-LR | AUG - UI MI | AUG - UU | AUG - UUA5 | AUGa - FRtA | AUGg - LVLA-A | AUGg - LRLA-A | AUH - LUAS | AUHA - LB | AUHA - LBLU | AUHA - LC | AUHA - LCLU | AUHF - LAL | AUHF24LB | AUHF - LBL | AUHG - LV | AUHG18LV | AUHG - LVLA | AUHG - LVLB | AUHG - LR | AUHG - LRLA | AUHG - LRLE | AUtG - LVLA | AUtG - LVLC | AUy - LUAR | ABHA - GATH | AU - UFAAR | AUG - UFARR | AUG - UFASR | AUGa - LATF | AUxA - GALH | AUxA - LALH | AUXB - GBLH | AUXB - GALH | AUXB - LALH | AUXB - LATF | AUxD - GALH | AUxD - LALH | AGHF - LA | AGHF - LAC | AGHG - LV | AGHG - LVCA | AGHG - LVCB | ABHF24LB | ABHG - LVtB | ABGA - LATF | ABHA - GATH | ABHA - LBtH | ABGG - LRtA-A | ABGG - LVtA | ABGG - LVtA-A | ABHA - LB | ABHA - LBT | ABHA45LC | ABHA - LCT | ABHF - LBT | ABHG - LR | ABHG - LRtA | ABHG - LRtE | ABHG - LVtA | AWGA - LATF | ASHA - LEC | ASHA - LKC | ASHG - LE | ASHG14LE | ASHG - LECA | ASHG14LECA | ASHG - LECB | ASHG - LJ | ASHG - LMCA | ASHG - LT | ASHG - LTCA | ASHG - LTCB | ASHG - LUCA | ASHG - LJCA

HIYASU AC models

HSA - LKC | HSB - LDC | HSG - LECA | HSG - LJCA | HSG - LFCA | HSG - LFCC | HSG - LMCA | HSG - LTCA | HSG - LUCA | ACH - H UIA-LH | ACH - H UIAT-LH | ACH - UIA-LL | ACH - UIA-LM | ACH - UIAT-LM | HR - UA | HRA - LALU | HRA - LATN | HRA - LATU | HRA - LBTU | HRA - LCTU | HRC - LCTU | HRF - LALU | HRF - LBLU | HRF - LBTU | HRG - LHtA | HRG - LLtA | HRG - LLtB | AUH - UIA-LR | AUH - UIAT-LR | AUH - UIA-LV | HU - UA | HUA - LATN | HUA - LATU | HUA - LBLU | HUA - LCLU | HUF - LAL | HUF - LBL | HUG - LVLA | HUG - LVLB | HUG - LHLE | HUG - LHtA | ABH - UIA-LR | ABH - UIAT-LR | ABH - UIA-LV | HGF - LAC | HGG - LVCA | HGG - LVCB | HBA - LBT | HBA - LCT | HBF - LBT | HBFF - LBT | HBG - LRtA | HBG - LRtE | HBG - LVtA | HBG - LVtB | HSA - LKC | HSG - LECA | HSG14LECA | HSG - LJCA | HSG - LMCA | HSG - LTCA | HSG - LUCA

* The asterisks stand for any character in the asterisk' position.

ORDER CODE:

INKNXFGL001R000	Fujitsu RAC and VRF systems to KNX Interface with binary inputs (to remote controller) - 1 unit
-----------------	---

INCLUDED COMPONENTS:

- Intesis Gateway,
- Installation Manual.

Warranty: 36 months.